

PUREFX™



VEHICLE DEODORIZATION PROTOCOL

PureFx – CLO₂ Canister – In-Situ Generator

Directions:

1. Open Canister and remove foil pouch. Open foil pouch and remove membrane. Place membrane back in cup. Discard foil pouch and desiccant.
2. Fill cup with water to designated fill line on cup.
3. Screw cap back on to canister.
4. Let CLO₂ generation develop for 45 minutes before using. Water will turn yellow in color.
5. Start vehicle – turn air conditioning on – select high fan mode.
6. Unscrew cap from canister - place in cup holder. Make sure vehicle doors and windows closed.
7. Let A/C run for 10-15 minutes.
8. After 10-15 minutes – open both car doors. Wait a few seconds for excess CLO₂ to exit vehicle.
9. Switch mode to full heat on high fan.
10. Close both doors – let heat circulate for 10-15 minutes.
11. After 10-15 minutes - open both doors.
12. Let excess CLO₂ dissipate before going into car.
13. Carefully take the canister out of cup holder and screw in the top to re-seal
14. If necessary – place canister back into car (take cap off) and turn on re-circulation fan on high for another 5-10 minutes with doors closed.
15. Remove canister after 5-10 minutes and air out car. Place cap back on the canister and repeat in another vehicle.